

ORIGINAL PET DOOR INSTALLATION

TOOLS REQUIRED FOR INSTALLATION

Hammer and Awl (or Nail) • Drill and $\frac{3}{8}$ " Drill Bits • Sabre Saw
• Phillips Screwdriver • Safety Goggles

1. DETERMINE TEMPLATE PLACEMENT - For Original plastic pet door, use PLASTIC SLIDE AS TEMPLATE, center template (width) in middle of door; hold in place. Measure your pet at shoulder and position the top of the template 2" taller than your pet's shoulder.

Important: Under no circumstances should the bottom edge of the rough opening be less than 3" from the bottom edge of the wood door.

2. OUTLINE PET DOOR OPENING - With PLASTIC SLIDE TEMPLATE held in place, use a pencil to draw around the edge of template onto door Use a nail or awl to mark four inside edge corner holes for drilling.

3. DRILLING HOLES - Drill the four $\frac{3}{8}$ " diameter individual corner holes).

4. CUTTING THE OPENING - Using a sabre saw, begin with one of the corner holes and carefully cut along the pencil line.

5. ASSEMBLY & ADJUSTMENT - Insert outer frame (no flap) into opening from exterior side. Make certain frame is flush with door surface. Caulking is recommended under outer frame. Place inner frame (with flap) into opening from inside of door, hold in place, then install screws and tighten until snug.

Do not over-tighten.

As with any home improvement project, if you do not have the tools or skills to properly install your pet door, we suggest using a professional handyman or licensed contractor.