

“Electronic” E-Cat Door™

INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION

- Hammer and Awl (or Nail) • Drill and 3/8" Drill Bit
- Sabre Saw • Phillips Screwdriver • Wear Safety Goggles

- 1. DETERMINE TEMPLATE PLACEMENT** - The die-cut template is located in the center of pet door. Remove beauty ring from outer frame; lift out template. Center template (width) in middle of door; tape in place. Position the top of the template approximately 2" taller than your pet's shoulder.

Important: Under no circumstances should the bottom edge of the template cutout be less than 4" from the bottom edge of the wood door.

- 2. OUTLINE PET DOOR OPENING** - With template taped in place, use a pencil to draw around the inside edge of the template onto door. Use a nail or awl to mark outer screw holes.


- 3. DRILLING HOLES** - Next: Drill the four (4) 3/8" diameter outer screw holes.

- 4. CUTTING THE OPENING** - Mark and drill four (4) 3/8" diameter inside corner saw-out starter holes. Begin with one of the inside 3/8" corner holes. Using a sabre saw, cut along inside edge pencil line.

- 5. ASSEMBLY AND ADJUSTMENTS (SEE DIAGRAM)** - Insert outer

frame (A) into opening from exterior side (frame must be flush with door surface). Place inner beauty ring (B) into opening from inside door and hold in place. Install screws (C) and tighten until snug. **Do not over-tighten.**

- 6. ADJUSTABLE FLAP OPERATION** - Using the red dial (D) located on door's lower side, adjust to match desired operation as indicated by embossed symbols on door.



LOCKED.
Both In or Out



UNLOCKED.
Active



UNLOCKED.
Free In or Out (Open)

Limited Lifetime Warranty

All parts are guaranteed to be free of manufacturers defects in workmanship and materials, excluding flap or breakage of the glass panels. Lifetime warranty applies to the original purchaser only with proof of sales receipt. All defective parts will be replaced free of charge. The replacement part will be sent when we receive proof of purchase and a check in the amount of \$10.00 to cover shipping and handling, Payable to: IDEAL PET PRODUCTS, INC.

This warranty is void if damage to material is due to improper installation or intentional abuse.

IDEAL Pet Products, Inc., 24735 Avenue Rockefeller, Valencia, CA 91355
Attn: Pet Products Warranty Dept.


As with any home improvement project, if you do not have the tools or skills to properly install your pet door, we suggest using a professional handyman or licensed contractor.

“Electronic” Pet Door Training-

In case your animal has never used a pet door before you may need to use a gentle approach to training him to become comfortable with the idea. Especially in the case of a mechanically activated pet door, an adjustment period will be necessary for the first 4-5 days.


Try using the door for a couple of days, setting the dial in the “FREE” position allowing the pet to freely come and go.

After a few days, set the dial to its “ACTIVE” setting. By now your animal will come and go comfortably through his new private entrance!



How to Connect and/or Replace the Battery-

Remove screw on battery panel (**Fig.1**). Remove panel (**Fig.2**). Insert 9v battery (supplied) into plug (**Fig.3 & 4**). Insert battery into compartment (make sure battery wire is pushed into wire slot) (**Fig.5**). Replace panel and reattach screw (**Fig.6**). Your pet door is now ready for operation. We recommend you replace the battery every 6 months.



E-Sensor™ Collar and Pendant-

The E-Sensor™ Pendant allows only the pet(s) wearing it to activate the pet door.

For best results, be sure to keep pendant clean.

Your “Electronic” Pet Door includes one E-Sensor™ Collar and Pendant set (additional E-Sensor™ Collar and Pendant sets can be ordered by calling toll free 1.800.378.4385 or by email at service@idealpetproducts.com).

